

How to select your KOMPAKT 37 signal tower

► STEP 1

Select the signal tower of your choice with or without buzzer, with the appropriate connection, housing colour, voltage and number of tiers.

Part numbers can be found on page 50.

ClassicLOOK



- 1-5 tiers
- With or without buzzer
- M12 plug or cable
- Black or silver finish

DesignLOOK



► STEP 2

Select up to two extension tubes.

optional:



Extension tube
Order no. **960 698 02**

optional:



Extension tube
Order no. **960 698 04**

► STEP 3

Select the appropriate fixing accessories for your application, using for example a tube and base or a bracket mount.

Single Hole Mounting

Bracket Mounting

Base Mounting

Single Hole Mounting

Bracket Mounting

Base Mounting



Bracket for base mounting
Order no. **960 630 02**



Base with integrated tube
Order no. **960 698 01**



Bracket for base mounting
Order no. **960 630 06**



Base with integrated tube
Order no. **960 698 03**

► STEP 4

Where appropriate, select the bracket and the contact box.



Bracket for base mounting with concealed cable entry
Order no. **960 000 14**



Bracket for base mounting
Order no. **960 000 01**



Corner fixing bracket
Order no. **960 000 41**



Contact box for cable exit at side
Order no. **975 840 01**



Contact box with magnetic base and cable exit at side
Order no. **975 840 04**



Bracket for base mounting with concealed cable entry
Order no. **960 000 55**



Bracket for base mounting
Order no. **960 000 54**

Go to the signal devices page on: www.werma.com

Here you can use the selection tool „Configurator“ to select the Kompakt 37 signal tower according to your requirements.

With the help of intuitive questions and pictures you will be able to make your choice with just a few mouse clicks.