EcoStruxure Operator Terminal Expert

Configuration software for Harmony ranges supporting gestures and intuitive user interface designs

References (continued)

Printed Buildtime licenses

Description	License type/No. of Stations	Application transfer cable		Reference
		PC side port	Terminal side	
EcoStruxure Operator Terminal Expert Professional Single license	Single/1	USB/ Ethernet	Harmony GTU Harmony GTO *(1)* Harmony STO7 Harmony ST6 Harmony STM6 Harmony *i*PCs and other PCs	HMIPELCZLSPMZZ
EcoStruxure Operator Terminal Expert Professional Group license	Group/3			HMIPELCZLGPMZZ
EcoStruxure Operator Terminal Expert Professional Team license	Team/10			HMIPELCZLTPMZZ
EcoStruxure Operator Terminal Expert Professional Entity license	Entity/100			HMIPELCZLEPMZZ
EcoStruxure Operator Terminal Expert Basic Single license	Single/1		Harmony STO7 Harmony ST6 Harmony STM6	HMIEELCZLSPMZZ

Digital Buildtime licenses *(2)*

Description	License type/No. of Stations	Application transfer cable		Reference
		PC side port	Terminal side	
EcoStruxure Operator Terminal Expert Professional Single license	Single/1	USB/ Ethernet	Harmony GTU Harmony GTO *(1)* Harmony STO7 Harmony ST6 Harmony STM6 Harmony *i*PCs and other PCs	HMIPELCZLSPAZZ
EcoStruxure Operator Terminal Expert Professional Group license	Group/3			HMIPELCZLGPAZZ
EcoStruxure Operator Terminal Expert Professional Team license	Team/10			HMIPELCZLTPAZZ
EcoStruxure Operator Terminal Expert Professional 3 months Single license	Fixed term Single/1			HMIPEXCZLSRAZZ
EcoStruxure Operator Terminal Expert Professional Entity license	Entity/100			HMIPELCZLEPAZZ
EcoStruxure Operator Terminal Expert Basic Single license	Single/1	_	Harmony STO7 Harmony ST6 Harmony STM6	HMIEELCZLSPAZZ

Printed Runtime license

Description	License type/No. of Stations	Application transfer cable		Reference
		PC side port	Terminal side	
EcoStruxure Operator Terminal Expert Runtime license for Windows	Single/1	USB/ Ethernet	Harmony *i*PCs and other PCs	HMIRTWCZLSPMZZ
EcoStruxure Operator Terminal Expert Web Viewer Runtime Single License	Single/1	_	Harmony GTU Harmony ST6 Harmony STM6 Harmony iPCs and other PCs	HMIWRT001
EcoStruxure Operator Terminal Expert Web Viewer Runtime Team License	Team/10			HMIWRT010
EcoStruxure Operator Terminal Expert Web Viewer Runtime Entity License	Entity/100			HMIWRT100

Digital Runtime license

Description	License type/No. of Stations	Application transfer cable		Reference
		PC side port	Terminal side	
EcoStruxure Operator Terminal Expert Runtime Single license for Windows	Single/1	USB/ Ethernet	Harmony *i*PCs and other PCs	HMIRTWCZLSPAZZ

USB Media Installer *(3)*

Description	Reference
EcoStruxure Operator Terminal Expert USB Media Installer	HMIBTUSB32