Control and signalling units Ø 22

Harmony® XB4 metal

Pushbuttons and switches for harsh environment

Spring return pushbuttons, unmarked or with marking

Assembly of other products using body/contact assemblies: see page 16


PF101202

ZB4 BC580


PF101213

ZB4 BC28001


PF101203

ZBZ 1902


PF101214

ZBZ 60


PF101208

Contact + ZB4 BC28001


PF101209

Contact + ZB4 BC28001RA

Pushbuttons with integrated bellows

Shape of head	Colour of push	Symbol	Reference	Weight kg
Heads only, Ø 37 mm (IP 66 + IP 69K) without marking				
Flush	White	–	**ZB4 BC180**	0.036
	Black	–	**ZB4 BC280**	0.036
	Green	–	**ZB4 BC380**	0.036
	Red	–	**ZB4 BC480**	0.036
	Yellow	–	**ZB4 BC580**	0.036
	Blue	–	**ZB4 BC680**	0.036
	Grey	–	**ZB4 BC780**	0.036
	Light blue	–	**ZB4 BC980**	0.036
Heads only, Ø 37 mm (IP 66 + IP 69K) with marking *(1)*				
Flush	Black	Bell	**ZB4 BC28001**	0.036
		0	**ZB4 BC28021**	0.036
	White	I	**ZB4 BC18023**	0.036
	Red	0	**ZB4 BC48021**	0.036
	Green	I	**ZB4 BC38023**	0.036

Accessories

Description	Function	Reference	Weight kg
Protective guard in plastic	Protection against accidental operation	**ZBZ 1902** *(2)*	0.010
Boot for contact block ZBE 10●, ZBE 10●3 and ZBE 50● *(3)*	Protection against dust ingress (IP 5x)	**ZBZ 60**	0.098

(1) Heads are fixed relative to the position of the contact blocks:

- contact blocks are normally used in the "vertical" position.

- to mount the contact block in the "horizontal" position, it is necessary to order an alternative head with the symbol rotated by 90°. Please add the suffix «RA» in the end of the references for alternative heads of your choice.
Example: ZB4 BC28001 becomes ZB4 BC28001RA.

(2) For heads with the RA suffix (ZB4 BC●●●●RA) used with a guard, it is necessary to order the dedicated guard ZBZ 1902RA.
(3) Restriction for use: refer to the product instruction sheet on www.schneider-electric.com.

Other versions	Customization with other texts or symbols Please consult our Customer Care Centre.