Control and signalling units Ø 22
Harmony® XB5 plastic
Pushbuttons and switches for harsh environment
Spring return pushbuttons, unmarked or with marking

Assembly of other products using body/contact assemblies: see page 16


PF101212

ZB5 AC680

Pushbuttons with integrated bellows

Shape of head	Colour of push	Reference	Weight kg
Heads only, Ø 37 mm (IP 66 + IP 69K) without marking			
Flush 	White	**ZB5 AC180**	0.024
	Black	**ZB5 AC280**	0.024
	Green	**ZB5 AC380**	0.024
	Red	**ZB5 AC480**	0.024
	Yellow	**ZB5 AC580**	0.024
	Blue	**ZB5 AC680**	0.024
	Grey	**ZB5 AC780**	0.024
	Light blue	**ZB5 AC980**	0.024
Heads only, Ø 37 mm (IP 66 + IP 69K) with marking			
Other versions	Customization with marking at your choice (texts or symbols) Rotation of head for horizontal mounting of the contact block *(1)* Please consult our Customer Care Centre.		


PF101203

ZBZ 1902

Accessories

Description	Function	Reference	Weight kg
Protective guard in plastic	Protection against accidental operation	**ZBZ 1902** *(2)*	0.010
Boot for contact block ZBE 10●, ZBE 10●3 and ZBE 50● *(3)*	Protection against dust ingress (IP 5x)	**ZBZ 60**	0.098


PF101214

ZBZ 60

(1) Heads are fixed relative to the position of the contact blocks: contact blocks are normally used in the "vertical" position. It is necessary to order an alternative head with the symbol rotated by 90° in order to mount the contact block in the "horizontal" position (see images page 2). Please add the suffix «RA» in the end of the references for alternative heads of your choice.
(2) For heads with the RA suffix (ZB5 AC●●●●RA) used with a guard, it is necessary to order the dedicated guard ZBZ 1902RA.
(3) Restriction for use: refer to the product instruction sheet on www.schneider-electric.com.