

I/O System – 750 and 753 Series, Supply/Segment Modules

Contents

Function	Description	Item Number			Page
		Standard	Extended Temperature	Pluggable	
Power Supply 24 VDC	Power Supply; 24 VDC	750-602*	750-602/025-000	753-602	324
	Power Supply; 24 VDC/5 ... 15 VDC	750-623			324
	Power Supply; 24 VDC; Fuse holder	750-601*			325
	Power Supply; 24 VDC; Fuse holder; Diagnostics	750-610*			325
	System Power Supply; 24 VDC	750-613*			326
	24 VDC with Bus Power Supply				
	230 VAC/DC	Power Supply; 0 ... 230 VAC/DC	750-612*	753-612	327
	24 VAC	Power Supply; 24 VAC; Fuse holder	750-617		328
	120 VAC	Power Supply; 120 VAC; Fuse holder	750-615		328
	230 VAC	Power Supply; 230 VAC; Fuse holder	750-609		329
DALI Multi-Master DC/DC Converter	Power Supply; 230 VAC; Fuse holder; Diagnostics	750-611			329
	DALI Multi-Master DC/DC Converter			753-620	330
Potential Distribution	Potential Distribution	750-614*		753-614	331
	Potential Distribution; 8x 24 V	750-603		753-603	332
	Potential Distribution; 8x 0 V	750-604		753-604	332
	Potential Distribution; 16x 24 V	750-1605*			333
	Potential Distribution; 16x 0 V	750-1606*			333
	Potential Distribution; 8x 24 V/8x 0 V	750-1607			333
Filter Modules	Field Supply Filter (Surge); 24 VDC; Higher isolation	750-624/020-000*			334
	Field Supply Filter (Surge); 24 VDC; Higher isolation; Without power jumper contacts	750-624/020-001*			334
	Field Supply Filter (Surge); 24 VDC; Higher isolation; Ground fault diagnostics	750-624/020-002			334
	Field Supply Filter (Surge); 24 VDC	750-624			335
	Field Supply Filter (Surge); 24 VDC; Without power jumper contacts	750-624/000-001			335
	Supply Filter; 24 VDC; Higher isolation	750-626/020-000*	750-626/025-001		336
	Supply Filter; 24 VDC; Higher isolation; Ground fault diagnostics	750-626/020-002			336
	Supply Filter; 24 VDC	750-626	750-626/025-000		337
Local Bus Extension	Bus Extension End Module	750-627			338
	Bus Extension Coupler Module	750-628			338
Spacer Modules	Binary Spacer Module	750-622			339
	Spacer Module; Active			753-1629	340
	Spacer Module; Active; Without power jumper contacts			753-1629/000-001	340
	Spacer Module; Passive			753-629/020-000	340
Distance Modules	Distance Module	750-616*			341
	Distance Module; 24 VDC/230 VAC	750-616/030-000			341
	Distance Module	750-621			341
End Module	End Module	750-600*	750-600/025-000		342
Ex i		See Section 5.9			
*This module is also available as a variant of the 750 XTR Series.		See Section 6			