

Accessories – coded safety switch PSENcode

PSEN cs3/cs4,
PSEN ma1.4
actuator capsPSEN cs bracket
stop swinging door

Description Type	Features	Quantity	Order number
One-way screw to secure the actuator	▶ Stainless steel ▶ Drive: one-way slot (safety screw)		
PSEN screw M4x10	▶ M4, 10 mm ▶ Suitable for PSEN cs3/4/5/6	10	540 308
PSEN screw M4x12	▶ M4, 12 mm ▶ Suitable for PSEN cs3/4/5/6	10	540 309
PSEN screw M4x16	▶ M4, 16 mm ▶ Suitable for PSEN cs3/4/5/6	10	540 310
PSEN screw M4x20	▶ M4, 20 mm ▶ Suitable for PSEN cs3/4/5/6	10	540 313
PSEN screw M4x26	▶ M4, 26 mm ▶ Suitable for PSEN cs3/4/5/6	10	540 314
PSEN screw M5x10	▶ M5, 10 mm ▶ Suitable for PSEN cs1/2	10	540 311
PSEN screw M5x20	▶ M5, 20 mm ▶ Suitable for PSEN cs1/2	10	540 312
End caps PSEN cs3/cs4, PSEN ma1.4 actuator caps	Suitable for PSEN cs3/4 actuator	50	540 335
Mounting bracket PSEN bracket	Suitable for PSEN cs3/4 ¹⁾	1	532 110
PSEN mag/cs bracket straight	Suitable for PSEN cs3/4/5/6	2	532 111
PSEN cs bracket stop swinging door	Suitable for PSEN cs5/6 (set for switch and actuator)	1	532 108
PSEN cs bracket stop sliding door	Suitable for PSEN cs5/6 (set for switch and actuator)	1	532 109

¹⁾ for actuator and switch, 1 of each required

Cable selection:

From page 138

Keep up-to-date
on coded safety
switches
PSENcode:

 Webcode:
web150412

Online information
at www.pilz.com